

SPINNAKER KIT INSTALLATION

1. Install downhaul fairlead 2" above the deck line.
2. Install topping lift fairlead one half the distance from the deck to the jib hook.
3. Install halyard fairlead just above jib hook.
4. Install spinnaker pole bracket on front of mast 18" from deck line.
5. Install 3" halyard cleat at a convenient point on the mast.
6. Install spinnaker sheet snatch blocks on rub rail 18" from stern, with open end of the blocks toward stern.
7. Tie shock cord and topping lift line together and lead through topping lift and downhaul fairleads and tie.
8. Lead spinnaker halyard through spinnaker fairlead.
9. Tie shock cord to one end of spinnaker halyard and attach free end to chain plate. Tie carbine hook on free end of spinnaker halyard.
10. Attach plastic clew shackle and plastic clew ring to spinnaker.
11. Lead spinnaker sheets aft outside of side stays and around snatch blocks.

SIDEWINDER SPINNAKER GEAR

